

1. Audio & Midifileplayer

4300	MIDJPRO mit SSD 240 Multimedia Player	2290
4947	KETRON Lounge Multimedia Player	1760
4948	Lounge Multimedia Player mit SSD 240GB	1890

1.1 Zubehör Midifile Player

1005	Ständer zu Midjpro	120
4563	Tasche zu Midjpro, SD40 & Lounge	75
4564	Koffer Deluxe zu Midjay, Midjpro	140
4955	Ständer zu Lounge	120
4956	Koffer zu Lounge	110

1.2 Zubehör Midjpro / SD7

4588	Hard disk Kit zu MIDJPRO / SD7 / SD9 /	200
4589	Installations kit ohne Hard disk für MIDJPRO	80

2. Keyboards

4614	Ketron SD7, Swiss edition tuning	3190
4637	Ketron SD9 PRO live station	3990
4691	Ketron SD7	2990
4750	Ketron SD60 Arranger/Player Keyboard mit	4290
4960	Ketron Event	4890
4984	Ketron Event61	4690

2.1 Zubehör Keyboards

3855	Koffer für SD 5/ 7/ 8/ SD80	240
4330	Tasche für SD5/7/ 80/ 9 / SD60 / EVENT	200
4642	Koffer für SD9 / SD60	260
4972	Koffer für Event	250
4974	Koffer DELUXE für Event mit Rollen	270
4987	Koffer für Event 61/Event Chrom	240
4990	Koffer DELUXE für Event61/Chrom mit	270
4993	Tasche für Event 61/Event Chrom	200

2.11 Kit SSD

4621	Kit SSD 120GB zu	135
4622	Kit SSD 240GB zu	180
4951	Kit SSD 480GB zu	230

3. Expander/Soundmodul

2800	Ketron EVM	2790
2803	Ketron Bundle: EVM + Monitor + Bag	2990
4301	Ketron SD1000, Professional Sound Module	420
4633	Ketron SD40 Expander, Swiss edition tuning	2090
4690	Ketron SD40	1890
4749	Ketron SD90 Expander	2690
4985	Ketron EventX	3990

3.1 Zubehör Expander/Soundmodul

1004	Ständer zu SD40	120
2801	Ständer zu EVENTX	120
2802	Ständer zu EVM	120
4454	Tasche für KlaviPro, SD2, SD1000	40
4646	Koffer zu SD40	110
4753	Koffer zu EVENTX, SD90	130
4801	Ständer zu SD90	100
4816	Tasche (Bag) zu EVENTX, SD90	75

4. Keyboards Chromatic

4639	Ketron SD80 Chromatic arranger & player	5590
4842	Ketron SD60K Chromatic arranger & player	6590
4992	Ketron EVENT Chrom DO1BN BI	6999

Netzteil

3448	Alimentatore 15V 40W für GP10A, GP50,	100
3715	Alimentatore Switching esterno Netzteil zu	100
4095	Alimentatore Switching esterno 9 volt 12W	90
4594	Netzteil / Alimentatore esterno 9V 40W für	100
4627	Alimentatore Switching 15V/60W esterno	100

Pedale

1091	Sustain Pedal Serie MS / Midjay	50
1337	K8 MIDI Pedalboard	440
1523	13 Effekt pedal Mod. FS13	220
1821	6 Effekt Pedal Mod. FS 6	150
2728	Volumen Pedal zu Ketron X neues Modell	80
2730	Sustain Pedal Piano Type	60

Pen Drive AUDYA

4171	Pen Drive (USB-Stick) Sound Upgrade zu	70
4195	Pen Drive 2011 Styles & Sound Upgrade zu	100
4327	Pen Drive 2012 "Song Styles Pop Hits" for	90
4651	Pen Drive Styles 2016 for Audya Series	90

Pen Drive MIDJPRO

4656	SD Serie Style Vol. 1, 9PDKP5 for MIDJPRO	70
4657	SD Serie Style Vol. 2, 9PDKP6 for MIDJPRO	70
4658	SD Serie Style Vol. 3, 9PDKP7 for MIDJPRO	70
4659	SD Serie Style Vol. 4, 9PDKP8 for MIDJPRO	70

Pen Drive MIDJPRO, SD7, SD80, SD40

4660	Song Style POP, 9PDKS1 for MIDJPRO,	70
------	-------------------------------------	----

Pen Drive SD7, SD80

4652	SD Serie Style Vol. 1, 9PDKP1 for SD7,	70
4653	SD Serie Style Vol. 2, 9PDKP2 for SD7,	70
4654	SD Serie Style Vol. 3, 9PDKP3 for SD7,	70
4655	SD Serie Style Vol. 4, 9PDKP4 for SD7,	70

USB Pendrive für SD9 SD60 SD90

4751	Pen Drive STYLE POP Lounge für SD9 SD60	70
4752	Pen Drive Audya Style Vol. 1 für SD9 SD60	70
4782	Pen Drive Audya Style Vol. 2 für SD9 SD60	70
4783	Pen Drive International Style Vol. 1 für SD9	70
4798	Pen Drive Audya Style Vol. 4 für SD9 SD60	70
4799	Pen Drive Audya Style Vol. 5 für SD9 SD60	70
4800	Pen Drive Audya Style Vol. 6 für SD9 SD60	70
4881	Pen Drive Audya Style Vol. 3 für SD9 SD60	70
4918	Pen Drive Audya Style Vol. 7 für SD9 SD60	70
4919	Pen Drive Audya Style Vol. 8 für SD9 SD60	70
4920	Pen Drive Audya Style Vol. 9 für SD9 SD60	70
4921	Pen Drive Audya Style Vol. 10 für SD9 SD60	70